

Full Drum Indicator *IHE-500*

When replacing cutting fluids, lubricants or cleaning liquids, it is very common that waste oil or waste solution is transferred to a drum temporarily.

At that time, haven't you ever filled it too much and overflowed the waste oil or waste solution because the remaining amount was unknown?

The Full Drum Indicator <IHE-500> is the gauge to remind you the remaining amount of the drum capacity from the level of 1/3 to full.

When setting <IHE-500> to the small mouth of the drum, the floater begins to float upward with the liquid level if it comes to the level of 2/3, and the drum is full when the level point of the floater hits the top.

Now that <IHE-500> is set, you have no worry to care about the contents of the drum.

